



# INSTALLATION MANUAL OUTDOOR WALL MOUNTED

## **INDEX**

- 1: INSTALLATION CONDITIONS
- 2: BRACKETS INSTALLATION
- **3:** WIRING INSTRUCTIONS
- 4: CONTINUOUS RUN INSTALLATION



these instructions.










# 1. INSTALLATION CONDITIONS



## Prepare the ceiling conditions according to the dimension table

Porfile Sizes (mm	) Profile	Profile Exact Dimensions (mm)			Profile Exact Dimensions (ft)		
	Length	Width	Depth		Length	Width	Depth
300	N/A	N/A	N/A	1	N/A	N/A	N/A
600	622	72	91	2	2ft 1/2in	Oft 2 13/16 in	Oft 3 9/16 in
900	922	72	91	3	3ft 5/16in	Oft 2 13/16 in	Oft 3 9/16 in
1200	1222	72	91	4	4ft 1/8in	Oft 2 13/16 in	Oft 3 9/16 in
1500	1522	72	91	5	4ft 11 15/16in	Oft 2 13/16 in	0ft 3 9/16 in

1








WARNING: Shock hazard. Serious injury or death may occur.

Turn Off power before servicing or installing. Wire according to local and



**WARNING:** Failure to secure safety cables can lead to injury or death!






# 3. WIRING INSTRUCTIONS

- ▶ Refer to the last page for wiring instructions.
- ► Follow carefully wiring diagram for various dimming protocols.
- ▶ Before beginning the wiring process, double check the type of connection specified.
- **T1** Type fixture only have an input, and cannot be used for daisy chained fixtures.

## **CONTINUOUS RUNS**

**T2** Type fixtures have though wiring and are meant to be daisy chained.



May daicy chain longth (A minimum of 18 AMC or 0.752 mm is required)

# Wiring Color Codes

	Ground	Line	Neutral	Dimmed Line	0-10V +	0-10V -	Dali +	Dali -
UL System	Green	Black	White	Orange	Red	Grey	Red	Orange
CE System	Yellow/Green	Brown	Blue	N/A	Red	Black	Red	Black

### Wiring Instructions for continuous runs (Daisy Chained Fixtures)

		max daisy chain length (A minimum of 16 AwG of 0.752 min is required)					
System	Voltage	"L" Output	"S" Output	"H" Output	"W" & "T" Outputs		
UL	120VAC - 60 Hz	100 ft.	50 ft.	36 ft.	50 ft.		
	277VAC - 60 Hz	200 ft.	100 ft.	70 ft.	100 ft.		
CE	240VAC - 50/60 Hz	45m	23m	17m	23m		


A

**WARNING:** Do not exceed the rated wattage of the through wiring cables or the connectors. For all continuous runs, refer to factory shop drawing indicating exact dimensions and feed locations.





## 4. CONTINUOUS RUN INSTALLATION



**WARNING:** Do not exceed the rated wattage of the through wiring cables or the connectors. For all continuous runs, refer to factory shop drawing indicating exact dimensions and feed locations.





#### **LINE-TO-LINE CONNECTOR:**


When Provided with Line-to-Line Connectors, fixtures will be Type 2 (Daisy chained) as show on page 3 and will have an Input cable and an Output cable with specific length.

These Cables shall be connected and terminated On-site.

Line-to-Line Connectors will have a separate instruction manual included in the fixture's packaging, giving detailed instructions on how to connect the leads properly. This step requires following the below wire labeling closely to prevent any damage to the fixtures.

A

Failure to follow the wiring color coding and connectors pin labeling will void the fixtures warranty.



For 0-10v dimming, the fixture are provided with two (2) cable leads, one with a 3 pin connector for power and the other with 2 pins connector for dimming wires. follow below connector labeling for termination of wires.


### MALE / FEMALE


When fixtures are ordered for continuous runs, (Daisy Chained), fixtures will be provided with MALE / FEMALE Connectors.

Connectors are factory installed on Input and Output cables leads.



Failure to follow the wiring color coding and connectors pin labeling will void the fixtures warranty.







**WARNING:** The connectors pins labeling can be found inside connector, embossed on the wire terminals. Always double check factory wiring order before connecting terminating the cables on-site.

